Propeller Parameters for Maximum Efficiency



PROP MATRIALS: Propeller lumber hardness and dryness should match (e.g. birch and walnut match well for color and hardness). Use glue that has working time.

By: Gerald Thornhill - f1camel@yahoo.com